



CurrieTech IZIP Electric Bicycle and Battery Care Tips

Folding and Operation

1. When folding the e-bike, take care not to pinch electric cables connected to handle bars.
2. While going up hills in Pedal Assist mode, it is best to apply gentle, even pressure to the pedals.
3. Do not inflate tires beyond 65 psi.

Battery and Power

1. Charging the battery:
 - **Connect charger to the battery first, then to the wall socket.**
 - Charge the battery every time the e-bike is used (deplete it the first three charges to “break in” the battery for best performance).
 - Do not charge the battery for more than 24 hours.
 - The battery takes 4 – 8 hours to charge completely.
 - Charger indicator light is **orange** when charging and **green** when fully charged.
 - For a full charge, leave the battery on the charger for an hour after the green charger light goes on.
2. Turn the e-bike power switch to the “off” position when not in use to avoid depleting battery life. The “sleep” function on the e-bike engages after five minutes of no activity. Cycle the e-bike off and on to re-activate the battery.
3. Cold weather will reduce the 15 - 22 mile range of the e-bike.
4. The battery can be removed with the key for charging at work. You may need to firmly tug the battery to fully dislodge it from the bike.

Securing the Bicycle

1. To properly secure the e-bike, run the U-lock through the **bike rack**, and the **frame**.
2. **Remove** the pannier. When locking the e-bike in a public area, also consider removing the front and back lights.

Other Notes

1. Read the owner’s manual for more information.

For **routine maintenance**, contact PSU Bike Hub at 503.725.9006 or bikehub@pdx.edu. For **warranty item repairs**, contact Bike n Hike at 503.736.1074 or info@bikenhike.com. For **other questions**, contact Zach Henkin at zach@driveoregon.org

